Instructions For Use

Proper inflation is necessary to use this product and is explained in 8 easy steps!

Inflating the Inner Grid and the Outer Ring

1. The inner grid should be inflated orally with about two large breaths of air for an average person. Do not use more air, two breaths is all that is needed. Close the valve.



2. Bunch up the SSR and move the contained air around to separate both layers of plastic. The SSR cannot be made to lie flat unless the layers are separated.





3. The SSR should be about the size of a soccer ball when bunched up.




4. Inflate the outer ring orally until it is firm.

5. Close the valve.
Place each SSR
single layer in direct
sunlight on a flat
non-abrasive surface
until the packing
lines relax.



6. This should take from 10 minutes to 30 minutes depending on the intensity of the areas not separated.



Instructions For Use Continued...

7. If the SSR still does not lie flat, measure the diameter. A properly inflated SSR is 60 inches or 152.4 cm in diameter.




8. If the SSR is smaller, use the deflation tube provided to let air out of the inner grid until it lies flat.



Excessive air in the grid section, deep packing lines and failure to separate both layers of plastic will all cause the outer edge to curl and distort.







How To Use Solar Sun Rings™

Once the Solar Sun Rings are inflated, cover up to 70% to 80% of the surface of your pool with Solar Sun Rings by placing the blue colored side on the water. More coverage than 70% of the surface on deep pools and 80% on shallow pools is not necessary. Keep the upper surface of the Solar Sun Rings™ clean and clear for the best solar effect.

Care Of Solar Sun Rings™

Proper care of this product will greatly extend its useful life, so special attention needs to be taken when stacking or cleaning the product. Refrain from walking on Solar Sun Rings™ or from stacking on pool decking and concrete surfaces which are designed to be abrasive to prevent slips and falls. When Solar Sun Rings™ are not on the pool water, refrain from stacking in direct sunlight as the product can burn whatever items that may lie underneath. To clean Solar Sun Rings™, simply mix a solution of water, pine cleaner, and vinegar. Clean your rings by wiping off residue on a monthly basis with the solution to ensure the bestperformance and appearance.

For more information regarding Solar Sun Rings™, feel free to call us at 1-866-756-2704 at ext. 208 or visit our website, www.solarsunrings.com



STORAGE GUIDE

The following are guidelines to storing your Solar Sun Rings for maximum performance and lifespan:

STORAGE DURING THE SWIMMING SEASON

- Solar Sun Rings may be removed and stacked on a completely shaded area, free from any sunlight throughout the day. Any surface where Solar Sun Rings are placed must be smooth and non abrasive. Placing them over grass, plants, or soil is not recommended.
- If necessary, Solar Sun Rings may be folded into quarters (fold in half once, then fold again). Deflation of the outer ring or the inner grid will not be necessary.
- Solar Sun Rings may also be hung by the attached loop on a non abrasive hook beside a non abrasive surface beneath a completely shaded area. They must also be hung at least 2 inches away from any external heat source such as a light or an outdoor heater. (Loop not available on the Solar Spa Cover.)

STORAGE DURING THE WINTER, OFF SEASON

- If local temperatures remain over 35° Fahrenheit (2° Celsius), then keeping Solar Sun Rings on the pool can be possible, but occasional cleaning of the rings may be necessary. If this method is preferred, deflation of the outer ring or the inner grid will not be necessary. Storing them under a winter cover on the pool is not recommended.
- If local temperatures are less than 35° (2° Celsius), or if storage away from the pool is preferred, then Solar Sun Rings may be stored away for long periods of time. First, deflate the outer ring and the inner grid by inserting the supplied deflation stems in the valves until no air is present, then completely clean, dry, and fold the rings as mentioned above. Place the Solar Sun Rings in a non abrasive and sealed container that will not be deformed or altered over a long period of time. The container may be placed in a cool and dry place such as a storage shed or a garage. Leaving the container outdoors or in an area exposed to the elements must be avoided and is not recommended.
- After storage over a long period of time, make sure Solar Sun Rings™ are warmed up to room temperature. The Solar Sun Rings may be opened individually and be inflated according to the Inflation Instructions provided with each ring. Folding creases will relax and fade under sufficient sun exposure within 15 to 30 minutes. Once proper care is maintained and instructions are followed, your Solar Sun Rings will perform as designed, generating heat for your pool.

For further questions regarding Solar Sun Rings, feel free to call us at 1-866-756-2704 ext. 208 or email us at warranty@solarsunrings.com.